

60301.855 Surrogate Parameter

"Surrogate Parameter" means a measurable physical or chemical property that has been demonstrated to provide a direct correlation with the concentration of an indicator compound, can be used to monitor the efficiency of trace organic compounds removal by a treatment process, and/or provides an indication of a treatment process failure.