

## **64651.32 Disinfectant Contact Time**

"Disinfectant contact time" means the time in minutes that it takes for water to move from the point of disinfectant application or a previous point of disinfectant residual measurement to a point before or at the point where residual disinfectant concentration is measured. Disinfectant contact time in pipelines is calculated by dividing the internal volume of the pipe by the flow rate through the pipe.

Disinfectant contact time within mixing basins and storage reservoirs is determined by tracer studies or an equivalent demonstration to the State Board.